


SYMPTOM: Compressor vibration noise.

CORRECTION:

- Pushing on the copper tubing in one direction or the other may stop the vibration noise from happening.
- Tightening or loosening the compressor mounting bolts may stop any vibration noise from cabinet.



Tightening or loosening the compressor mounting bolts may stop any vibration noise from cabinet.

